



RUFFNECK™ TROUBLESHOOTING TIPS

1. Heater is not operating
 - 1.1 Check all fuses in heater control box.
 - 1.2 Check secondary high limit protection circuit breaker. If tripped, further inspection is required to determine cause. Refer to manual.
 - 1.3 Check remote disconnect switch and circuit breaker.
 - 1.4 Check voltage supplied to the heater – refer to the heater data plate for voltage requirements.
 - 1.5 Check thermostat by turning it and check continuity with a multimeter.
 - 1.6 Check the condition of the disconnect switch if the heater is so equipped. Measure continuity through the disconnect by engaging the switch.
 - 1.7 Verify that there is a jumper wire present between terminals 5 and 6 on the terminal block located in the control box.
2. Contactor is chattering.
 - 2.1 Check supply voltage.
 - 2.2 Check wiring connections. Tighten all loose electrical connections.
- 2.3 Check thermostat for continuity (See 1.4). If thermostat does not break continuity, replace thermostat.
3. Contactor is burned or welded
 - 3.1 Check the contactor for burn marks and blackening. Replace the contactor.
 - 3.2 Check incoming power to the heater to ensure there are no voltage fluctuations.
4. Heat exchanger is dirty
 - 4.1 Clean the heat exchanger using compressed air.
5. Pressure relief device(s) (PRD) has released
 - 5.1 If there are signs that the PRD has released fluid, PRD indicator is broken, blackening around the PRD exit hole, or there are fluid stains visible on the top louver, shut the unit down immediately.

CAUTION: DO NOT USE WATER TO CLEAN THE HEATER.

CAUTION: IF PRD HAS RELEASED, SEND THE UNIT IN FOR REPAIR OR REPLACE THE CORE.

CAUTION: DO NOT FORCE CONTACTS CLOSED

- 5.2 Check for restricted air flow, bad motor, broken thermostat or malfunctioned high limit.



6. Heater is cold on top and warm on bottom.
 - 6.1 The core may have lost its vacuum. Check the PRD for signs of loss of fluid and verify that the PRD label indicator is not broken. If PRD has released, send the unit in for repair or replace the core.
 - 6.2 If the PRD does not indicate loss of fluid, the heater should operate normally. Check for loss of fluid on a weekly basis as a minimum.
 - 6.3 The ambient temperature may be too low. If the ambient temperature is very cold the top of the core will be colder than the bottom – this is normal.
7. Unit cycles on high limit—unit turns on and turns off within less than 5 minutes.
 - 7.1 Check and see if the PRD has released fluid. Core may have lost most or all of its fluid. If PRD has released, send the unit in for repair or replace core.
 - 7.2 The core may be dirty, fan may not be working or may be turning the wrong way (the fan must rotate clockwise as seen from the front of the unit) objects may be stuck in the heat exchanger for drying or warming up – remove any items from the exchanger.

CAUTION: DO NOT USE THE HEATER AS A CLOTHES DRYER.

8. The Ground Fault Interrupter (GFI) trips on the main panel, or heater blows fuses
 - 8.1 Check that you have a fuse of the proper amperage rating.
 - 8.2 Check for loose or frayed wiring.
 - 8.3 If condition is not observable, send heater in for repair.
 - 8.4 Change sensitivity of GFI.
9. The fan is turning but very little air comes from the front of the heater.
 - 9.1 Check fan rotation and ensure that the fan turns clockwise as seen from the front of the heater. Refer to the Owner's Manual for more information.
 - 9.2 Check motor winding resistance and verify that they are balanced.
 - 9.3 Check fan blade set screws to ensure fan blade is not loose on the motor shaft.

Ruffneck™ Factory

5918 Roper Road
Edmonton AB T6B 3E1
Phone: 780-466-3178
Fax: 780-468-5904
Email: info.ths@thermon.com
www.thermon.com