

QSWS1000

Installation Instructions

1. Attach side supports to unit using supplied #10 self tapping screws. See: 1

2. Tighten roof to side supports, using supplied spring-nut and #10-24 x ½" machine screw. See: 2

• Suggested tools: 5/16" hex head driver and Screw Gun set to low clutch setting.

• Please adhere to all local laws and building codes.

