iO-TC 24VAC, 7-DAY TIME CLOCK



KEY FUNCTIONS

TIMER - SELECTS AND REVIEWS PROGRAMS

MANUAL - SELECTS ON/AUTO/OFF

CLOCK - PUTS TIMER IN CLOCK SET MODE


DAY - SETS CURRENT DAY

HOUR - SETS CURRENT HOUR (AM/PM)

MIN - SETS CURRENT MINUTE

Ø - TIMER RESET

ON - LED INDICATING ON STATUS ON IN THE OCCUPIED MODE





PROGRAM COMBINATIONS

FACE GETTING STARTED

The iO-TC electronic 7-day, low voltage timer can control up to 8 ON/OFF events from a selection of 15 daily program combinations. The TC-24-7 is powered by 24 VAC and also has a rechargeable lithium battery backup to maintain the real time clock and program schedules in the event of a power failure.

SETTING THE CLOCK

- 1. Press the 🕱 button to reset timer before programming. This will assure that the timer is in the AUTO mode.
- 2. Hold the **CLOCK** key down and while pressing **DAY** key, **HOUR** key and **MIN** key respectively to set the current DAY, HOUR and MINUTE.

SETTING DAILY ON/OFF SCHEDULES

Important: Follow each step in careful sequence to assure proper programming.

- 1. Press the **TIMER** key. The LCD screen will display
- 2. Press the **DAY** key to select any of the 15 combinations of daily programs to fit your scheduling needs. The LCD will display each combination as illustrated in the Program Combinations chart above.
- 3. Press the **HOUR** key and **MIN** key to set the desired HOUR and MINUTE for **1**ON. Make sure that AM or PM is correct.
- 4. Press the **TIMER** key again and the LCD screen will display
- 5. Press the **DAY** key to select the same program combination as in step 2.
- 6. Press the **HOUR** key and **MIN** key to set the desired HOUR and MINUTE for **1**OFF. Make sure that AM or PM is correct.
- 7. If additional daily ON/OFF programs are required, press the **TIMER** key again. The LCD screen will display ON OFF programs are required, press the **TIMER** key again. The LCD screen
- 8. Follow steps 1 6. You can program as many as 8 ON/OFF functions. If only 1 ON/OFF function is required, simply press the **CLOCK** key after finishing steps 1-5 and the timer will start the ON/OFF program for event 1.

REVIEWING PROGRAMS

1. To review programs, each press of the **TIMER** key will display the ON/OFF schedules for each of the 8 events.

_____ means no event for a specific program number.

MANUAL OVERRIDE AND INITIAL SYSTEM STARTUP

1. The timer should be left in the **AUTO** mode for automatic operation. If the **MANUAL** button is set to the **ON** or **OFF** position, the timer will stay in the override mode. To set the timer back to the auto mode, press the **MANUAL** button to **ON** or **OFF** to match the auto mode time of day setting then place it in the **AUTO** position. The symbol __ on the LCD above the word AUTO indicates that the timer is in the AUTO mode.

