



## PFACT Actuator and Pulley Set Installation

Please read these instructions carefully. The PFACT Actuator must be mounted and installed correctly or it will void the warranty. Instructions below reference only the first pulleys that the cable comes in contact with after leaving the actuator arm. All other pulleys will be mounted based on your application.


**Pulley set must be mounted a minimum of 24" from the end of the extended actuator arm.**



**Pulley sets tracks must align on the same plane with actuator arm.**




**Pulley sets tracks must be no more than 1/2" apart and align with the actuator arm.**




## PFACT Actuator and Single Pulley Installation

Please read these instructions carefully. The PFACT Actuator must be mounted and installed correctly or it will void the warranty. Instructions below reference only the first pulley that the cable comes in contact with after leaving the actuator arm. All other pulleys will be mounted based on your application.


**Pulley must be mounted a minimum of 24" from the end of the extended actuator arm.**



**Pulley track must align on the same plane with actuator arm.**



**Pulley track must align with the actuator arm.**



## PFACT115-24 & PFACT230-24 INLET ACTUATOR




## WARRANTY

J&D Manufacturing warrants all products are free from defects in materials and workmanship under normal use for the period of one year from date of purchase. Our warranty does not cover normal or regular wear and tear. J&D Manufacturing can repair or replace at our option, any product or part of the product that is found to be defective. Our warranty applies to materials only, and does not include return freight, delivery, loss or damage to personal property, cost of removal or installation, any incidental or consequential damages or labor. This warranty does not apply to products which are misused, abused, altered, improperly installed or subject to negligence. All warranties must be approved through our warranty department. The original purchaser must present a copy of the invoice for the defective product. One year is our standard warranty unless specified on our literature or in the installation instructions or user manuals.

**ALL ELECTRICAL WORK SHOULD BE COMPLETED BY QUALIFIED PERSONNEL AND MEET NATIONAL, REGIONAL AND LOCAL CODES.**

Please read over all instructions carefully before you begin.  
If you have any questions please call your local dealer, or contact J&D Manufacturing at 1-800-998-2398.

## Actuator



## Potentiometer - 10 Kohms

