

INSTALLATION INSTRUCTIONS

Drain Pan for Lodronic UH model series HCH

Drain Pan Installation

1. Remove the #10-16 x 1/2" screws around the bottom perimeter of the unit heater and remove the bottom casing panel"
2. In the bottom casing panel remove the knockout in the center.

Note: Verify that the coil has slots in that bottom as seen in figure 1.1. Contact customer service if incorrect.

3. Remove the retaining nut"from the bulkhead fitting but leave the gasket on.
4. With the drain pan oriented as seen in Figure 1.2, align the drain pan hole with the knockout hole and install the bulkhead fitting.

Note: The gasket must be against the top side of the drain pan in the recessed area.

5. Thread on the retaining nut and tighten by hand, then apply a wrench and tighten 1/4 turn more to compress the gasket.
6. Re-install the bottom casing panel with the drain pan aligned properly under the coil.

Note: Internal thread of bulkhead fitting is 1/2" NPT; External thread of the bulkhead fitting is 3/4" GHT which allows additional field supplied adapters to be used.

Figure 1.1 - Coil



IMPORTANT

1. The use of this manual is specifically intended for a qualified installation and service agency. All installation and service of these kits must be performed by a qualified installation and service agency.
2. These instructions must also be used in conjunction with the Installation and Service Manual originally shipped with the appliance, in addition to any other accompanying component supplier literature.

Figure 1.2 - Drain Pan Assembly

