









Models

ARB24-SR(-T)

ARX24-SR(-T) Flexible Version

| Technical Data | |
|--|--|
| Power supply | 24 VAC ± 20% 50/60 Hz |
| 1 ower suppry | 24 VDC ± 10% |
| Power consumption running | |
| holding | |
| Transformer sizing | 5 VA (class 2 power source) |
| Electrical connection | ½" conduit connector |
| | 18 GA plenum rated cable |
| | 3 ft [1m], 10 ft [3m], 16 ft [5m] |
| Overload protection | electronic throughout 0° to 95° rotation |
| Operating range Y | 2 to 10 VDC, 4 to 20 mA |
| Feedback output U | 1 to 10 VDC, max 0.5 mA |
| Input impedance | 100 kΩ (0.1 mA), 500 Ω |
| Angle of rotation | 90°, adjustable with mechanical stop |
| Torque | 180 in-lb [20 Nm] |
| Direction of rotation | reversible with protected \frown/\frown switch |
| Position indication | handle |
| Manual override | external push button |
| Running time | |
| ARB24-SR | 90 seconds |
| ARX24-SR | 300, 150, 90 seconds, |
| | constant independent of load |
| Humidity | 5 to 95% RH non-condensing |
| | (EN 60730-1) |
| Ambient temperature | -22°F to +122°F [-30°C to +50°C] |
| Storage temperature | -40°F to +176°F [-40°C to +80°C] |
| Housing | NEMA 2/IP54 |
| Housing material | UL94-5VA |
| Agency listings† | cULus according to UL 60730-1A/-2-14, |
| | CAN/CSA E60730-1:02, CE according to |
| | 2004/108/EC and 2006/95/EC for line voltage |
| | and/or –S versions |
| Noise level | <45 dB(A) |
| Quality standard | ISO 9001 |
| † Rated impulse voltage 800V, Control pollution degree 3, Type of action 1 | |

[†] Rated impulse voltage 800V, Control pollution degree 3, Type of action 1 (1.B for -S models)



AR...24-SR Actuators, Proportional

Wiring Diagrams



X INSTALLATION NOTES



CAUTION Equipment damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.



Actuators may also be powered by 24 VDC.



Only connect common to neg. (-) leg of control circuits.



APPLICATION NOTES



The ZG-R01 500 Ω resistor converts the 4 to 20 mA control signal to 2 to 10 VDC, up to 2 actuators may be connected in parallel.

WARNING Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

